

Antifreeze Urban Warrior Series

Read Through All Steps Before Starting

Step 1 – Drain unit completely of all water in the main tanks by opening the **Drain Valve**.

Step 2 – Remove Water Filter, clean and reinstall.

Step 3 – Connect the Antifreeze hose to the main drain line with the **Drain Valve** open.

Step 4 – Open the **Antifreeze Valve** and perform Start up Procedures (Including Low Water Override) with **High Pressure Valve** Open.

Step 5 – With the hose pointing in a safe direction press and hold the **Water On/Off** Button on control until antifreeze comes out of the High-Pressure hose. (Caution: Make sure pump does not run dry for an extended period)

Step 6 – Immediately close the **High-Pressure Valve** and run unit for five seconds and then release the **Water On/Off** Button. (This insures both return lines are protected)

Step 7 – Connect the High-Pressure Hose to the Garden fill hose with the Crowfoot fitting.

Step 8 – Open **High-Pressure Valve** and hold **Water On/Off** button unit until you can see antifreeze in the clear tube going into the top of the water tank.

Step 9 – Turn off unit and connect High Pressure hose to the top of the Antifreeze tank. Connect Garden Fill hose to its home fitting. Close the **Antifreeze and Drain Valve**.

Recapturing Antifreeze Urban Warrior Series

Step 1 – Fill Water Tank.

Step 2 – Turn unit on with the **High-Pressure Valve** open and immediately press the **Water On/Off** button.

Step 3 – Close the **High-Pressure Valve** or turn off the **Water On/Off** when the antifreeze tank is full.

Step 4 – Disconnect the High-Pressure Hose from the antifreeze tank and continue normal operation.

Special Note – Every time you recapture antifreeze, you will reduce the ability of the antifreeze to protect the unit in low temperatures.